

Chevy 6 Lug Shock Extension Brackets – Installation Instructions



For some vehicles it is easier to install the brackets with the shock in the vehicle.

- 1) Remove the lower shock bolt from the lower control arm.
- 2) Turn the shock 180 degrees.
- 3) Using the bolt provided, place the shock extender into the shock mount.
- 4) Using the factory bolt, install the shock extender onto the lower control arm.
- 5) Tighten the upper shock mount.

