

Fat Bob's Garage

Rear Lift Block Instructions

Technical Support: (801) 395-2134 Mon-Fri 9:00am-5:30pm MST

www.FatBobsGarage.com

Read entire instruction sheet thoroughly before starting. Wear safety glasses. Use safe vehicle lifting practices.

1. Place wheel chocks in front and behind the front tires. Make sure vehicle will not move forward or back.
2. Lift rear of vehicle by frame jacking points and support with jack stands on each side. Make sure vehicle is stable.
3. Support rear differential with a floor jack. (See Figure 1)
4. Loosen the 4 U-bolt nuts on the passenger side. Pull U-bolts up and out. Remove the axle mounting plate. Lower the floor jack down until there is 3 inches of space between the leaf spring and the rear axle. (See Figures 2 & 3)
5. Place new lift block between the leaf spring and axle with the alignment dowel pins lined up. (See Figure 4)
6. Jack the axle up and align spring dowel with lift block hole. Slide the new U-bolts over the leaf spring and through the mounting plate.
7. Tighten U-bolt nuts evenly and to specification.
8. Repeat Steps 4 through 7 on the driver's side.



Figure 1



Figure 2



Figure 3



Figure 4